


KW-DP90 USER MANUAL



- (1) A1,B1 are the Profibus input wire terminal blocks, A2,B2 are the Profibus output wire terminal blocks.
- (2) Switch is the termination resistors switch, when the connector is at the end of the Profibus, you should put the switch on.
- (3) When the RX and TX indicator flashes, it means the connector is receiving or sending data. Otherwise, if the LEDs long-on/long-off, the network fault.
- (4) Operating voltage(From DB9) DC 4.25V~5.25V, <10mA, max 32 connectors in the same network.
- (5) Baud Rate:9600~12Mbit/s; Temperature -20 ~ 75 °C; Dimensions: 70 * 39.5 * 16mm; Material: PC + flame retardant

The diagnostic function can only work at the baud rate: 9600-3Mbit/s

A, Used in slave station:

- (1) **RX, TX** flash: the communication is OK.
- (2) **RX** long-on: there is some station in error state on the bus, the error station occupation of the bus, continuous transmission.
- (3) **TX** long-on: this station is in error state and occupation of the bus, continuous transmission.
- (4) **RX** long-off: Profibus break, short circuit or master station is in error state.
- (5) **TX** long-off: station in error state; station number is wrong, not the same as master configuration; GSD file error.

B, Used in master station:

- (1) **RX, TX** flash: the communication is OK.
- (2) **RX** long-on: there is some station in error state on the bus, the error station occupation of the bus, continuous transmission.
- (3) **TX** long-on: this station is in error state and occupation of the bus, continuous transmission.
- (4) **RX** long-off: this master station break with other slave station, or short circuit, or wrong configuration.
- (5) **TX** long-off: this master station in error state, or the configuration is not finished.